

detachable plug

Instructions - detachable plug

1. Slide the cover off by pushing away from the plug. **(See Illustration 1)**
2. Insert the trimmed end of the cord into the plug pocket, nearest to the polarized blade (wide blade). Be sure that the ribbed side of the cord goes over the right piercing point, and the smooth side of the cord goes over the left piercing point. **(See Illustration 2)**
3. Slide the plug cover back onto the wire plug **(See Illustration 3)**, and route the plug to the nearest outlet.

